


ECKART Interpretations of 2012 Liquid Eyeliner Trend Colors

Spring/Summer 2012

Mysterious Moments

Black Obscure

1.0% SynCrystal Sparkling Silver
5.0% Black 2 (CI 77266) (20%)



Vulnerable White

10.0% SynCrystal Silver



Liquid Eyeliner

INCI Name	Product Name	%W/W	Supplier
A		100.00	
Aqua	Water	q.s.	
Glycerin	Glycerin 85%	4.00	www.wagnerlanolin.de
Xanthan Gum	Keltrol CG-T	0.20	www.cpkelco.com
Magnesium Aluminum Silicate	Veegum HV	0.30	www.rtvanderbilt.com
Propylene Glycol	1,2-Propandiol	3.00	www.vwr.com
<i>Black 2</i>	<i>Black 2 (20% aqueous solution)</i>	q.s.	
B			
Stearic Acid	Kortacid 1895	2.00	www.akzonobel.com
Glyceryl Stearate	Aldo MS K FG	0.50	www.lonza.com
Oleyl alcohol	HD-Ocenol 90/95 V	0.50	www.cognis.com
C			
Synthetic Fluorophlogopite (and) Titanium Dioxide	SynCrystal see formulation	q.s.	www.eckart.net
Mica	Silk Mica	0.40	www.vwr.com
D			
Acrylates Copolymer	Covacryl E14	10.00	www.lcw.fr
Dimethicone (and) Trisiloxane	Xiameter PMX-1184 Silicone Fluid	5.00	www.dowcorning.com
Phenoxyethanol (and) Methylparaben	Uniphen P-23	0.50	www.induchem.com

Procedure:

1. Weigh in phase A and phase B separately and heat up to 75°C
2. Add phase B to phase A while stirring
3. Add phase C to phase AB stir until homogeneous
4. Cool down to RT and add phase D step by step while stirring
5. Stir until homogeneous
6. Fill into an appropriate container

For further questions, please ask your ECKART contact:

EUROPE

ECKART GmbH
E-mail: info.eckart@altana.com

UNITED STATES OF AMERICA

ECKART Cosmetic Colours LLC
E-mail: info.eckart.cosmetics@altana.com

ASIA

ECKART Asia Limited
E-mail: info.eckart.asia@altana.com

www.eckart.net